

# FITTING GUIDE

## SCHMIDT

# A few words before you get started

We would like to thank you for placing your trust in our company by recently purchasing a Schmidt kitchen! To get the very most out of your Schmidt kitchen for many years to come, it is vitally important to take the greatest of care during fitting.

This guide features a wealth of essential information to help you. Remember that you are not alone! If you have any questions or doubts, feel free to contact your Schmidt adviser!

You can also view this guide on our website at [www.homedesign.schmidt](http://www.homedesign.schmidt):  
Menu ► Fitted kitchens ► See also ► How to guides ► Fitting Guide

Your safety is one of our top priorities, so our units are designed and manufactured to satisfy the requirements of the EN 14749 European safety standard.

However, the person or company fitting the units is responsible for choosing the appropriate screws and wall fixings (refer to page 7).

Schmidt Groupe shall not be held liable if any units fall off the wall due to inappropriate fixings.

## Schmidt - the only certified manufacturer...



# FITTING GUIDE CONTENTS

Vocabulary	P. 4
Preparing the room and tools	P. 6
Act responsibly	P. 6
Safety advice and precautions during fitting	P. 6
Tools required	P. 7
Getting off to the right start	P. 9

## WHAT TYPE OF KITCHEN DO YOU HAVE?

### STRAIGHT-LINE KITCHEN

Go to P. 12

A. Getting started	P. 12
B. Fitting the base units and housings	P. 12
C. Adjusting and fitting the filler for housings and base units	P. 17

### L-SHAPED KITCHEN

Go to P. 19

A. Getting started	P. 19
B. Fitting a corner base unit	P. 19
C. Fitting a corner filler	P. 25

### KITCHEN WITH AN ISLAND OR PENINSULA

Go to P. 27

A. Getting started	P. 27
B. Fitting an island	P. 27
C. Fitting back panels on base units	P. 29

## CUTTING AND FITTING A SIDE SUPPORT OR FINISHING END PANEL P. 32

## OPTIONAL: FITTING THE PROTECTION STRIP P. 34

## FITTING THE WORKTOP AND SPLASHBACK P. 36

A. Cutting out for the sink and/or hob	P. 36
B. Assembling worktops	P. 38
C. Fitting a laminate splashback	P. 40

## FITTING WALL UNITS P. 42

A. Preparing to fit wall units	P. 43
B. Fixing wall units	P. 45
C. Fitting the filler for wall units	P. 48
D. Fitting the filler return for wall units	P. 50

## OPTIONAL: FITTING BUILT-IN LIGHTING INTO THE UNIT BASE P. 51


## FITTING APPLIANCES AND TAPS P. 53

## FITTING THE PLINTH AND PLINTH RETURN P. 59

## FINISHES P. 63


# VOCABULARY

## KITCHEN




## ISLAND

(FREESTANDING UNITS NOT FIXED TO THE WALL)




## PENINSULA






## BASE UNIT




## WALL UNIT



## DIFFERENT TYPES OF CORNER BASE UNIT


### "VARIABLE" CORNER BASE UNIT

(BAV/BAV1/BAVP/BAVPI/BAVIP/  
BAV2P/BAVIP1/BAVIP2)




### "DIAGONAL" CORNER BASE UNIT

(BAP)



### "RIGHT-ANGLED" CORNER BASE UNIT

(BAL/BALP/BALPS)



Some specific units come with their own fitting instructions.  
You will find these instructions in the sundries box.

# PREPARING THE ROOM AND TOOLS

Make sure that the room is ready (paint, tiling, etc.) before fitting your new kitchen.

USE the technical drawing provided by your designer to check the position of the electrical sockets and water fittings according to the layout of your kitchen. If necessary, consult a professional.

## FOR PEACE OF MIND GUARANTEED

- ✓ Make sure that you protect the floor in the work area
- ✓ Ensure that you have enough room to work (remove all items from the room except those that you will need)
- ✓ Keep all your tools within reach and fully charged

# ACT RESPONSIBLY

## KEEP YOURSELF SAFE




## PROTECT THE ENVIRONMENT



Our products have been awarded the NF ENVIRONNEMENT label, the only French ecolabel for the furniture and homeware sector, for their environmentally-friendly design. If you need to dispose of your old units, take the time to remove all metal and plastic components and then recycle accordingly.

# SAFETY ADVICE AND PRECAUTIONS DURING FITTING

- ✓ Switch off the water, electricity and gas before starting
- ✓ Use a stepladder instead of climbing on the units or boxes
- ✓ Use screws and fixings that are suited to the type of wall
- ✓ Always protect the visible side when sawing panels to avoid damaging or chipping the surface



expert advice




If you do not have a professional circular saw, you are advised to cut your panels from the underside:

Place the saw on the concealed side rather than the visible side (the side that can be seen once the kitchen has been fitted). This will prevent you from leaving visible chips.


# TOOLS REQUIRED

## YOUR TOOLBOX



Make sure that you have these tools within easy reach and ensure that any battery-powered tools are fully charged before starting to fit your kitchen. We will tell you what tools are required at each step.

## SCREWS AND WALL FIXINGS NOT SUPPLIED



The choice of screws and wall fixings is your responsibility or the responsibility of the professional fitter as applicable. Wall fixings are not supplied.

Choose the appropriate type of screws, wall fixings and drilling method according to the type and quality of your walls (hollow wall, solid wall, etc.) and the size and type of the units that you have chosen.

Units are fitted with brackets that can withstand 100 kg each, i.e. a maximum load of 200 kg according to the size of the unit. Our units are designed to satisfy the requirements of the EN 14749 standard and are capable of supporting the load appropriate for the dimensions of the units.

## PARTS IN THE SUNDRIES BOX




These parts are provided in the sundries box supplied with your kitchen (depending on the kitchen layout).




A

Guide




B

Socket




C

Leg




D

Air vent




E

Plinth clip



F

Filler strip return for wall units




FI

Batten



G

Back panel fixing bracket




H

Hinge cover




I

Drawer cover




J

Noise-cancelling discs



K

Handle




L

Worktop connectorbolt



M

White glue



N

Worktop jointing biscuit




O

Cyanoacrylate glue




P

Adhesive sealant



Q

Mounting plate for wall unit brackets



QI

Mounting plate for non-reinforced walls




R

Cap




S

Glass shelf bracket




T

Rear shelf bracket  
Front shelf bracket




U

Bracket




V

Small bracket




W

Plinth return clip




AA

Spotlight



BB

90° plinth corner joint




CC

180° plinth corner joint



DD

135° plinth corner joint



EE

225° plinth corner joint



FF

Handle screws



GG


Screws and fixings




HH

Connector screws


## ASSEMBLY DIFFICULTY



Easy



Medium



Hard


## NUMBER OF PEOPLE REQUIRED



x 1



x 2



x 3



expert advice

Throughout this guide, whenever you see this sign, you will receive practical tips to make the fitting process even easier.


# GETTING OFF TO THE RIGHT START

## TIPS FOR GETTING READY


1. Affix the technical drawings from your Schmidt adviser on the wall, so that you can easily refer to them.
2. Check and sort the units.
3. USING the technical drawing provided by your adviser, identify each unit and its location. Each parcel is identified by a label indicating the unit's reference number.

Affix the labels inside the corresponding units, so that you have the relevant reference number if you need to contact the after-sales service.

4. Start with the base units and housings. Put all other units in another room without removing their packaging.
5. Unpack the base units and housings, and then remove the drawers, fronts, shelves and fittings.



## REMOVE THE DOORS



Do not remove the fronts on wall units with lift-up mechanisms.




### Why remove the fronts?


During assembly, you will need access to the inside of the units.

Place the fronts in an adjacent room and protect them to avoid any damage. Do not remove the protective film from the fronts until you have finished fitting the units. Store the fronts on cardboard to prevent any damage.



## REMOVE THE DOOR FROM THE FRIDGE HOUSING





## REMOVE THE DRAWERS



## FIT THE LEGS ON THE BASE UNITS




## FIT THE LEGS ON THE HOUSINGS




expert advice

If necessary, the transport struts can be used as battens during the later fitting stages.

3




4




5



Pre-adjust the legs to fit to the height of the plinth.



6




7




# STRAIGHT-LINE KITCHEN

## A. GETTING STARTED




### WITHOUT AN ADJOINING WALL

Start with the housing if applicable.  
Otherwise, start at either end.



### KITCHEN WITH AN ADJOINING WALL

Start in the corner. Do not forget the location  
for the filler. Refer to your technical drawing.






### BETWEEN TWO WALLS

Start by centring the units.  
Finish each end with a filler.

## B. FITTING THE BASE UNITS AND HOUSINGS




Check against your  
technical drawing




HH





# 1 Mark the location of the different units and housings.




# 2 Fit the first unit.




If your floor is uneven, measure the height of the leg at the lowest point. The plinth must be adjusted to this height.







# 3 Cut out an opening in the back of the carcass to provide access to the plug socket.




## 3.a








expert advice

You are advised to allow easy access to the plug sockets that will be used for the appliances by positioning them behind an adjacent carcass. It is important to be able to quickly unplug a defective appliance.





**4** Make a cut-out in the sides for any pipes (if necessary).



**5**


Fix the housing to the wall.




Use fixings that are suited to the type of wall. Repeat the procedure in case of several housings.

This type of fixing is also mandatory for base units.

## 6 Position and level the units.






## 7 Use clamps to hold the units together.





## 8 Use clamps to hold the units together.



8.a




8.b




9

Leave a space for the dishwasher.




Space reserved for your dishwasher (45 or 60 cm).

1




10

Fix the last unit to the wall.





- 1 Use a straightedge or batten to check that the units on either side of the dishwasher are in alignment.
- 2 To fix the units to the walls, refer to step 5 on page 14.



## C.ADJUSTING AND FITTING THE FILLER FOR HOUSINGS AND BASE UNITS





Check against your technical drawing





### ADJUSTING A CARCASS FILLER (aligned with the carcass)

### ADJUSTING A FRONT FILLER (aligned with the unit front)



OR



1




1




2







Facing the wall






2



## ADJUSTING A CARCASS FILLER




## ADJUSTING A FRONT FILLER




# L-SHAPED KITCHEN

## A. GETTING STARTED


1 WALL



2 WALLS




3 WALLS



Start in the corner

## B. FITTING A CORNER BASE UNIT


VARIABLE CORNER BASE UNIT (BAV)




- 1 Remove the mobile filler from inside the carcass.





STEP 8





- 2 Fit the first corner unit while making sure that you leave the gap specified in the technical drawing.



### 3 Level the unit by adjusting the legs.




### 4 Mark the position of your worktop on the wall at the appropriate height.




### 5 Remove the unit and then fit the batten (to support the worktop).




Use fixings that are suited to the type of wall.




### 6 Put the corner unit back in position.



### 7 Fix the unit to the wall.




To fix the base units, refer to step 5 on page 14.






8

Position the second unit and fit the filler.





9

Join both units together using the filler.




10

Fix the second unit to the wall.




To fix the base units, refer to step 5 on page 14.


11



DIAGONAL CORNER BASE UNIT




RIGHT-ANGLED CORNER BASE UNIT




OR



Check against your technical drawing




1




2

Level the unit by adjusting the legs.




3

Remove the unit and fit the battens (to support the worktop).




4

Put the corner unit back in position as well as the next unit. Level the second unit by adjusting the legs.




## 5 Fix the second unit to the wall.







expert advice





To fix the base units, refer to step 5 on page 14.



## 6 6.a




## 6.b




## C. FITTING A CORNER FILLER (ALTERNATIVE SOLUTION TO A CORNER UNIT)




CORNER CARCASS FILLER



CORNER FRONT FILLER




1




2

Level the unit by adjusting the legs.




3








4

Mark the position of the worktop.



5

Fix the battens.



Remove the transport struts beneath the housings, so that you can use them as battens (refer to step 2 on page 10). If you do not have a corner base unit, you must use battens to reinforce the corner and support the worktop.

6

Fix the filler (two possibilities depending on the kitchen purchased).







CARCASS FILLER

(the filler is aligned with the carcass)

FRONT FILLER


(the visible part of the filler is aligned with the unit front)

OR




Do not trim the width of the fillers.

6.a



6.b



# KITCHEN WITH AN ISLAND OR PENINSULA

## A. GETTING STARTED

### ISLAND



Determine the position of the island before fixing. Position the island according to your technical drawing.

### PENINSULA




Start with the unit against the wall.


## B. FITTING AN ISLAND





Check against your technical drawing




If the total width of the island is greater than 2000 mm, you can skip this step.



If the island comprises two back-to-back units with a total depth greater than 700 mm, you can skip this step.




**1**




**2**

Screw the rear sockets to the unit.




**3**

Fit the front legs.




**4**

Use cyanoacrylate glue.




**5**

Fit the rear legs.







**6**



**7**

Level the units by adjusting the legs.




X2  
= plinth height


X2  
+5mm





## 8 Screw the units together.




## 9



## 10 Glue the rear legs to the floor.




### 10.a




### 10.c




### 10.e



### 10.b



### 10.d



### 10.f





## C. FITTING BACK PANELS ON BASE UNITS



The back panel is a decorative panel that is used to conceal the back of the carcasses when used in an island or peninsula (if your units are not positioned back-to-back).



Check against your technical drawing



1




expert advice



Measure the length and height of your island or Peninsula without forgetting to add the width of the dishwasher and the thickness of the side support or end panel if applicable.

2





expert advice




Adapt the dimensions of your back panel if necessary: if you need to trim the panel, make sure that the cut edges are at the top and against the wall.

3




4

Mark the locations for the brackets on the back of the carcasses and then fix the brackets.




5

Fit the back panel by sliding into the brackets.





6

To properly adjust the panel, use a mallet and a wooden block.





# CUTTING AND FITTING A SIDE SUPPORT OR FINISHING END PANEL

SIDE SUPPORT




FINISHING END PANEL




OR

SIDE SUPPORT



FINISHING END PANEL




OR




If an appliance is going to be fitted at one of the ends of the kitchen, start by positioning the worktop. Mark the location of the side support and then measure the distance from the floor to the underside of the worktop.




## SIDE SUPPORT




## FINISHING END PANEL




## OPTIONAL: FITTING THE PROTECTION STRIP




**I** Trim the side support by 6 mm with a circular saw.



- 2** The side support or finishing end panel to fit against the skirting board.




**3**



**4**

Remove the protective film from the double-sided adhesive tape and then position the strip against the side support or finishing end panel.




**5**

Put a bead of silicone on the end cap and clip onto the protection strip.



**5.a**




**5.b**




**6**

Position the side support or finishing end panel.



To fit the side support or finishing end panel, refer to step 4 on page 33.

# FITTING THE WORKTOP AND SPLASHBACK



If you have several worktops, identify where they are going to be fitted in the kitchen.

Position the worktops on the carcasses according to the technical drawing and check the dimensions.

Make sure that the worktops are facing the right direction: the decorative edging should be facing the front of the kitchen.



If you have purchased a Quartz worktop, you should refer to its specific fitting instructions.




You are advised to turn the worktop upside-down and cut along the underside to prevent chipping the surface finish with the saw blade.

## A. CUTTING OUT FOR THE SINK AND/OR HOB



Check against your technical drawing




**1**

Start by marking the outline of the units (where a cut-out is required) on the underside of the worktop.




Bowls must be positioned over a single unit. Cut-outs must be made within one unit



**2**



Turn the worktop over and you will see the location of the units.







## SINK





Sink instructions



Check whether you need to cut a hole for just the bowl or both the bowl and the drainer (refer to the instructions supplied with the sink).

## HOB




Hob instructions




Carry out the next steps (4 to 7) for the sink and then repeat for the hob.

- 4** Measure by how much the rim of the sink overlaps the worktop and use the measurement to mark the cut-out.




**5**

Then place wooden strips beneath the worktop to avoid splintering the surface when drilling.





wooden strips




**6**




Corners must be cut with a rounded edge. Use a hole saw or drill bit with a diameter of at least Ø10.



7




When the holes have been cut, carry the worktop on its side.



## B.ASSEMBLING WORKTOPS




Check against your technical drawing




1

Position the worktops. Using the glue provided, apply beads of glue across the entire thickness of the joint.




2

SPREAD out the glue.




The glue is not only used for assembling the worktops, but also for sealing the joint.


### 3 Insert the jointing biscuits.



### 4 Butt the worktops together.




### 5 Beneath the worktop, position and assemble the connector bolts supplied.




**expert advice**  
Before tightening the connector bolts, make sure that the upper surfaces of both worktops are properly aligned.

### 6 Remove the excess glue with a damp cloth.




### 7 Fit the worktops to the carcasses.



In units with a built-in appliance and covered with a panel or worktop, you must fit an air vent in the worktop or panel above the unit and also in the plinth.  
Example: in a fridge, air must be allowed to circulate.

- 8** Apply a bead of silicone between the worktop and the wall. Clean away any excess silicone.




expert advice

Use masking tape to create a clean joint.

**9**

expert advice


Protect your worktop with cardboard before fitting the wall units.





## C. FITTING A LAMINATE SPLASHBACK




Check against your technical drawing



- I** Check the dimensions and position of your splashback.




2



3


Switch off the electricity and remove the plug socket covers.




Consult an electrician.

4

Mark the position of the plug sockets on the back of the splashback.



5




expert advice




Use masking tape on both sides to drill a clean hole.


6




7




- 8** Apply silicone beads to the back of the splashback and then glue the splashback to the wall by applying gentle pressure.




**8.b**



- 9** Use the silicone to create a seal between the splashback and the worktop.



## FITTING WALL UNITS



Wall units are available in different heights.

Position them according to your layout plan and the general appearance that you are looking to create for your kitchen.

Position the wall units so that you can easily access their contents.



For the extractor hood, refer to the manufacturer's instructions.



**SAFETY INFORMATION:** the top of the wall units must be fitted at a height of at least 1000 mm above the floor; since they have not been designed to be stood or sat on.



## A. PREPARING TO FIT WALL UNITS



Check against your technical drawing



Use fixings that are suited to the type of wall.



Q



Q1




HH

Depending on the quality of your walls, either use plate Q or plate Q1, or refer to the safety datasheet.


**1**

Start by protecting your worktops with cardboard.




**2**

Mark the worktop cut-outs on the cardboard, so that you can see where you must avoid placing objects or applying pressure.






### 3 Draw a line representing the top of the units.



### 4 Starting in the corner, measure and draw the necessary space for each wall unit.



#### CASE 1


Wall fixing plate for reinforced walls

#### CASE 2




Wall fixing plate for non-reinforced walls and unit widths > 60 cm.

OR

### 5 Use the drilling template on page 69 of this guide to mark the positions for the mounting plates.





### 5 Use the drilling template on page 71 of this guide to mark the positions for the mounting plates.







6



Use fixings that are suited to the type of wall. The mounting plates must be fixed with three screws.

6



Use fixings that are suited to the type of wall. The mounting plates must be fixed with three screws.



## B. FIXING WALL UNITS



Check against your technical drawing




For a built-in spotlight, refer to page 51.




HH


**1** Release the hook.





**1.a**




**1.b**




**2** Hang the carcass on the wall.







### 3 Use the brackets to level the units. Tighten the brackets to keep the unit flat against the wall.




### 4 Repeat the procedure for each unit.









#### 4.a



#### 4.b







## C. FITTING THE FILLER FOR WALL UNITS



Check against your technical drawing













## ADJUSTING A CARCASS FILLER

(aligned with the carcass)

## ADJUSTING A FRONT FILLER


(aligned with the unit front)

OR




## ADJUSTING THE FRONT FILLER (aligned with the unit front).


5



6




7




## D. FITTING THE FILLER RETURN FOR WALL UNITS









Check against your technical drawing





**1** Measure the dimensions of the filler return.




**2** Mark the dimensions on the filler return.





**3**



**4**



**5**



## OPTIONAL: FITTING BUILT-IN LIGHTING INTO THE UNIT BASE

Spotlights must be controlled by a switch. The transformer must be accessible once the unit has been mounted.




Check against your technical drawing





For your safety, refer to the manufacturer's fitting instructions.




If you have any doubts about wiring the spotlight and transformer, consult a professional.





- 1** Connect the spotlight and then run the wire through the hole provided.



- 2** Thread the wire out the back of the unit.




- 3**





- 4** Fit the wall unit and connect the spotlight to the transformer.



To fit the wall units, refer to page 45.



- 5**



Until you have made all the connections, tape the wires to the top of the units.




# FITTING APPLIANCES AND TAPS

## A. FITTING THE MIXER TAP



Check against your technical drawing



You **MUST** purge the installation (i.e. clear the pipes of any impurities) before connecting the mixer tap to the network.

You must not use any tools when tightening the flexible hoses in the base of the tap.

If the tap is supplied with a filter, remember to fit the filter between the shut-off valve and the hose before fitting the tap.



Refer to the instructions supplied with the mixer tap


## B. FITTING THE SINK




Check against your technical drawing




Refer to the instructions supplied with the sink




Apply water-resistant glue to the sides of the cut-out in the worktop.




- 2** SPREAD OUT the water-resistant glue with a spatula.



- 3** Apply a bead of clear silicone around the outside of the cut-out.




- 4** Install the sink and check that it is flush with the worktop.




- 5** Fix the sink beneath the worktop according to the instructions provided.



Refer to the instructions supplied with the sink



- 6** Remove any excess silicone with a spatula and soapy water.



Call a plumber to connect the U-bend and water supply.



To keep the sink in place and ensure a watertight seal, the sink must be fitted on a layer of silicone. You must fit the brackets supplied in addition to the silicone joint.


## A. FITTING THE HOB




Check against your technical drawing




Refer to the instructions supplied with the hob




- 1** Apply water-resistant glue to the sides of the cut-out in the worktop.



- 2** SPREAD OUT the water-resistant glue with a spatula.



- 3** Install the hob and check that it is flush with the worktop.



Refer to the instructions supplied with the hob




Call an electrician to connect the hob.




## D. FITTING THE BUILT-IN FRIDGE




Check against your technical drawing



## 1 Screw the handle in place.




## 2 Fit and adjust the door.



expert advice

To adjust the hinges, refer to page 64.

## 3 Install the fridge. Fix the housing door to the fridge door.



Refer to the instructions supplied with the fridge


### SPECIAL CASE Fitting an American fridge




## E. FITTING THE OVEN



Check against your technical drawing



Refer to the instructions supplied with the oven



Refer to the instructions  
supplied with the oven



Refer to the instructions  
and call an electrician to  
connect the oven





## F. FITTING THE DISHWASHER AND FRONT



Check against your  
technical drawing



Refer to the instructions  
supplied with the dishwasher





You **MUST** protect the underside of the  
worktop above the dishwasher with the vapour  
barrier supplied with the dishwasher.

The after-sales service will reject any claims for  
swelling damage to the worktop caused by a failure to  
fit the vapour barrier.

expert advice



In the case of fully integrated  
dishwashers (without a visible control  
panel), make sure that you fix the  
handle to the front before fitting it to  
the appliance.




## H. FITTING THE EXTRACTOR HOOD



Check against your technical drawing




### BUILT-IN EXTRACTOR HOOD



Refer to the instructions supplied with the extractor hood

### DECORATIVE EXTRACTOR HOOD



Refer to the instructions supplied with the extractor hood

If there is a gap between the underside of the extractor hood and the carcass, use the protective end panels to protect the sides of the adjacent units.



Refer to the instructions and call an electrician to connect the oven



**SAFETY INFORMATION** - Position the height of the extractor hood according to the manufacturer's recommendations, which can be found in the instructions supplied with the extractor hood.


If the supplier does not recommend a specific height, allow a distance of 75 cm between the worktop and the underside of the extractor hood for a gas hob and 65 cm for an induction hob.

With a ceiling-mounted extractor hood for an island, create a supporting frame to reinforce the ceiling.

# FITTING THE PLINTH AND PLINTH RETURN




Check against  
your  
technical drawing





**1**

Mark the position of the plinths on the floor in order to measure the dimensions.



**2**

Mark the dimensions on the plinths and then cut accordingly.





**3**

Cut out openings for the fridge and dishwasher air vents.




Refer to the instructions supplied  
with the dishwasher







#### 4 Present the plinth and move into position.



#### 5 Clip in place.




#### 6 Measure and cut the plinth return.







- 7** Measure the plinth and cut a groove for the skirting board if required to fit against the wall.




- 8** Fit the clips.




- 9** Slide in the second part of the clips.




- 10** Fit the plinth corner joint.



- 11** Clean the plinth return and remove the protective film.




**12** Present the filler return and apply pressure.




**SPECIAL CASE**

With an L-shaped kitchen, there is no plinth corner joint in the 90° angle.




**SPECIAL CASE**

For a 180° joint




**SPECIAL CASE**

Air vent for a fridge housing




# FINISHES

This step involves adding the finishing touches to your kitchen (adjustments to the fronts, shelves, etc.) and thereby extending its service life.




## A. FITTING A SHELF


### 1 PANEL shelves.



### 2 GLASS shelves.







## B. FITTING CAPS ON WALL UNITS











## C. FITTING AND ADJUSTING THE FRONTS ON BASE AND WALL UNITS



1



2




3




## D.ADJUSTING LIFT-UP FRONTS


1




2




3



4




Refer to the instructions on the control unit and then replace the cover.




## E.ADJUSTING THE FRONTS ON DRAWERS AND PAN DRAWERS

1

1.a



1.b




CLICK




2





2.a



2.a




2.a




3






1



CLICK



4



expert advice




Reinforcement brackets are provided for pan drawers > 80 cm. The bracket must be screwed to the front once it has been adjusted.

## F. FITTING GLASS SIDES


1






2




3




4




5





6





7



8



## G. FITTING HANDLES






# DRILLING TEMPLATE

For fixing the wall unit mounting **p69**.


For fixing on non-reinforced walls **p71**.




The template must be printed to scale. To check the accuracy of the template, refer to the specific dimensions.



Represents the thickness of the carcass









**SCHMIDT**  
Home SCHMIDT Home